























 <p>EVAPORATOR TO COMPRESSOR</p>	<p style="text-align: right;"><b>24HO056511</b></p> <p>AUDI A3 - SEAT LEON / TOLEDO - VW GOLF 4/BORA - SKODA OCTAVIA 1996-99</p> <p style="text-align: right;">OEM: 1J1820743J</p>
 <p>DRIER TO EVAPORATOR</p>	<p style="text-align: right;"><b>24HO057511</b></p> <p>AUDI A3 - SEAT LEON / TOLEDO - VW GOLF 4/BORA - SKODA OCTAVIA 1996-99</p> <p style="text-align: right;">OEM: 1J1820741D / 1J1820741B</p>
 <p>COMPRESSOR TO CONDENSER</p>	<p style="text-align: right;"><b>24HO058511</b></p> <p>AUDI A3 - SEAT LEON / TOLEDO - VW GOLF 4/BORA - SKODA OCTAVIA 1996-99</p> <p style="text-align: right;">OEM: 1J0820721T</p>
 <p>EVAPORATOR TO ACCUMULATOR</p>	<p style="text-align: right;"><b>24HO059511</b></p> <p>AUDI A4 1.8T/1.9TDi/2.4/2.5TDi/2.6 VW PASSAT 1.6/1.8/1.9TDi/2.3VR5</p> <p>1996 – 2001</p> <p style="text-align: right;">OEM: 8D1260710F</p>
 <p>EVAPORATOR TO ACCUMULATOR</p>	<p style="text-align: right;"><b>24HO060511</b></p> <p>AUDI A4 1.8T/1.9TDi/2.4/2.5TDi/2.6 VW PASSAT 1.6/1.8/1.9TDi/2.3VR5</p> <p>1996 – 2001</p> <p style="text-align: right;">OEM: 8D1260740M</p>







 <p><b>ACCUMULATOR TO COMPRESSOR</b></p>	<p style="text-align: right;"><b>24HO061511</b></p> <p>AUDI A4 1.8T/1.9TDi/2.4/2.5TDi/2.6 VW PASSAT 1.6/1.8/1.9TDi/2.3VR5 1996 – 2001</p> <p style="text-align: right;">OEM: 8D0260707H</p>
 <p><b>COMPRESSOR TO CONDENSER</b></p>	<p style="text-align: right;"><b>24HO062511</b></p> <p>AUDI A4 1.8T/1.9TDi/2.4/2.5TDi/2.6 VW PASSAT 1.6/1.8/1.9TDi/2.3VR5</p> <p>1996 – 2001</p> <p style="text-align: right;">OEM: 8D0260701H</p>
 <p><b>EVAPORATOR TO COMPRESSOR</b></p>	<p style="text-align: right;"><b>24HO063511</b></p> <p>CITROEN XSARA</p>
 <p><b>COMPRESSOR TO CONDENSER &amp; CONNECTOR TO COMPRESSOR</b></p>	<p style="text-align: right;"><b>24HO064511</b></p> <p>ALFA ROMEO 145/146 TD</p> <p>1996&gt;</p> <p style="text-align: right;">OEM: 60605531</p>
 <p><b>CONNECTOR TO COMPRESSOR</b></p>	<p style="text-align: right;"><b>24HO065511</b></p> <p>CITROEN XANTIA 1.9 D/TD / 2.0HDi</p> <p style="text-align: right;">OEM: 6460J4</p>





 <p style="text-align: center;"><b>COMPRESSOR TO CONDENSER</b></p>	<p style="text-align: right;"><b>24HO066511</b></p> <p>CITROEN XANTIA 1.9 D/TD</p> <p style="text-align: right;">OEM: 6457YR</p>
 <p style="text-align: center;"><b>EVAPORATOR TO COMPRESSOR</b></p>	<p style="text-align: right;"><b>24HO067511</b></p> <p>FIAT PUNTO 1.1 / 1.2 1992-93</p> <p style="text-align: right;">OEM: 7779326</p>
 <p style="text-align: center;"><b>CONDENSER TO DRIER</b></p>	<p style="text-align: right;"><b>24HO068511</b></p> <p>FIAT PUNTO 1.7D -TD</p> <p style="text-align: right;">OEM: 46432112</p>
 <p style="text-align: center;"><b>COMPRESSOR TO CONDENSER</b></p>	<p style="text-align: right;"><b>24HO069511</b></p> <p>FIAT PUNTO 1.3JTD / 1.7D -TD</p> <p style="text-align: right;">OEM: 46464372</p>
 <p style="text-align: center;"><b>EVAPORATOR TO COMPRESSOR</b></p>	<p style="text-align: right;"><b>24HO070511</b></p> <p>FIAT PUNTO 1.1 / 1.2 1993-2000</p> <p style="text-align: right;">OEM: 46446257</p>

 <p>CONNECTOR TO COMPRESSOR</p>	<p style="text-align: right;"><b>24HO071511</b></p> <p>PEUGEOT 306 D / TD &gt;1997</p>
 <p>DRIER TO EVAPORATOR &amp; EVAPORATOR TO CONNECTOR</p>	<p style="text-align: right;"><b>24HO072511</b></p> <p>PEUGEOT 605 3.0 V6</p>
	<p style="text-align: right;"><b>24HO073511</b></p> <p>RENAULT LAGUNA 1.8</p> <p style="text-align: right;">OEM: 7700424666</p>
	<p style="text-align: right;"><b>24HO074511</b></p> <p>RENAULT MEGANE 1.9DTI 1998&gt;</p> <p style="text-align: right;">OEM: 7700431380</p>
 <p>CONDENSER TO DRIER</p>	<p style="text-align: right;"><b>24HO075511</b></p> <p>RENAULT MEGANE 1.9DTI 1998&gt;</p> <p style="text-align: right;">OEM: 7700426468</p>

	<p style="text-align: right;"><b>24HO076511</b></p> <p>RENAULT MEGANE 1.9DTI 1998&gt;</p> <p style="text-align: right;">OEM: 7700426586</p>
 <p style="text-align: center;">CONDENSER TO DRIER</p>	<p style="text-align: right;"><b>24HO077511</b></p> <p>SEAT IBIZA / CORDOBA 1993 – 1997</p> <p style="text-align: right;">OEM: 6KO820739B</p>
 <p style="text-align: center;">COMPRESSOR TO CONDENSER</p>	<p style="text-align: right;"><b>24HO078511</b></p> <p>SEAT IBIZA / CORDOBA 1.0 / 1.4 / 1.6 1999&gt;</p> <p style="text-align: right;">OEM: 6K0840721E</p>
 <p style="text-align: center;">COMPRESSOR TO CONDENSER</p>	<p style="text-align: right;"><b>24HO079511</b></p> <p>AUDI / VW GOLF 4 1997&gt;</p> <p style="text-align: right;">OEM: 1J0820721C</p>
	<p style="text-align: right;"><b>24HO081511</b></p> <p>RENAULT LAGUNA 1.8</p> <p style="text-align: right;">OEM: 7700424667</p>

	<p style="text-align: right;"><a href="#">24HO101TAC</a></p> <p>FORD FOCUS [ALL MODELS]</p> <p style="text-align: right;">OEM: 1062504</p>
	<p style="text-align: right;"><a href="#">24HO102TAC</a></p> <p>HONDA CIVIC 1996&gt;</p>
	<p style="text-align: right;"><a href="#">24HO103TAC</a></p> <p>MERCEDES W202/W208 Class C 1993&gt;</p> <p style="text-align: right;">OEM: 1122301056</p>
	<p style="text-align: right;"><a href="#">24HO104TAC</a></p> <p>MERCEDES 220D Class C 1993&gt;</p> <p style="text-align: right;">OEM: 6042301056 / A6042301056</p>
	<p style="text-align: right;"><a href="#">24HO105TAC</a></p> <p>OPEL CORSA C 2003&gt;</p> <p style="text-align: right;">OEM: 6850665</p>
 <p style="text-align: center;">CONDENSER TO DRIER</p>	<p style="text-align: right;"><a href="#">24HO106TAC</a></p> <p>RENAULT MEGANE 2.2TD 1998&gt;</p> <p style="text-align: right;">OEM: 7700426468</p>

 <p>COMPRESSOR TO CONDENSER</p>	<p style="text-align: right;"><a href="#">24HO107TAC</a></p> <p>RENAULT MEGANE [without H/L Pressure Switch]</p> <p>1998&gt;</p> <p style="text-align: right;">OEM: 7700426586</p>
 <p>COMPRESSOR TO CONDENSER</p>	<p style="text-align: right;"><a href="#">24HO108TAC</a></p> <p>SEAT IBIZA</p> <p>1993 – 1997</p> <p style="text-align: right;">OEM: 6K0820721A</p>
 <p>LUC</p>	<p style="text-align: right;"><a href="#">24HO109TAC</a></p> <p>RENAULT MEGANE / SCENIC [with H/L Pressure Switch]</p> <p>1998&gt;</p> <p style="text-align: right;">OEM: 7700426586</p>
	<p style="text-align: right;"><a href="#">24HO111TAC</a></p> <p>MAN TRUCKS</p>
	<p style="text-align: right;"><a href="#">24HO112TAC</a></p> <p>MAN TRUCKS</p>
	<p style="text-align: right;"><a href="#">24HO113TAC</a></p> <p>MAN TRUCKS</p>

	<p style="text-align: right;"><a href="#">24HO114TAC</a></p> <p>MAN TRUCKS</p>
 <p style="text-align: center;">COMPRESSOR TO CONDENSER</p>	<p style="text-align: right;"><a href="#">24HO115TAC</a></p> <p>VOLVO FH12 - FH16</p> <p>1998&lt;</p> <p style="text-align: right;">OEM: 3981056</p>
 <p style="text-align: center;">CONDENSER TO DRIER</p>	<p style="text-align: right;"><a href="#">24HO116TAC</a></p> <p>VOLVO FH12 - FH16</p> <p>1998&lt;</p> <p style="text-align: right;">OEM: 3962714</p>
 <p style="text-align: center;">CONDENSER TO DRIER</p>	<p style="text-align: right;"><a href="#">24HO117TAC</a></p> <p>VOLVO FH12 - FH16</p> <p>1998&lt;</p> <p style="text-align: right;">OEM: 3962717</p>